

0 Connection and Use of Test Equipment

Explanation of Symbols Used for Test Equipment and Components

Description	Symbol
ABS adaptor	
Socket box tester 35-pole	
Socket box tester 126-pole	
Signal generator	
Hand-held tester (HHT)	
Impulse counter scan tool	
On-off ratio tester	
Pressure gauge	
Digital multimeter	
Resistance substitution unit	
Bridge	
DANGER! High Voltage	
Brake pad wear indicator	

Description	Symbol
Pin	
Socket	
Battery	
DC generator	
DC motor	
Capacitor	
Coil	
Resistance	
Ground	
Systems check O.K.	
Fault	
Greater than	
Less than	
Short circuit	
Short circuit to positive	

Description	Symbol
Short circuit to ground	
Open circuit	
Direct current measured with multimeter	
Alternating current measured w/multimeter	
Direct voltage measured w/multimeter	
Alternating voltage measured w/multimeter	
Resistance measured with multimeter	
Signal generator Square wave form	
Signal generator Sine form	
Oscilloscope	
Adaptor wire with LED	

0 Connection and Use of Test Equipment

Explanation of Symbols Used for Test Equipment and Components

Description	Symbol
Top air outlets	
Top, bottom and door air outlets	
Bottom air outlets	
Top and bottom air outlets	
Normal setting	
Economy setting	
Center and side air outlets	
Automatic function	
Automatic blower speed regulation	
Defrost	

Description	Symbol
Recirculating air	
Minimum blower speed	
Maximum blower speed	
Dehumidify	
Normal setting (cooling)	
A/C compressor Off	
A/C On/Off (USA only)	
Off (no air intake)	
° C	
° F	
Residual engine heat utilization	


0 Connection and Use of Test Equipment

Connector Layout of Data Link Connector

38-pole Data Link Connector (X11/4)

Models 124, 129, 140, 170, 202, 208, 210

1	Ground, circuit 31 (W12, W15, electronics ground)	13	TN-signal (gasoline), HFM (ME)-SFI engines
2	Voltage, circuit 87 or circuit 15z	14	On-off ratio, Engine 119 LH-SFI, Engine 120 LH-SFI (right)
3	Voltage, circuit 30	15	On-off ratio, Engine 120 LH-SFI (left)
4	EDS Electronic diesel system	15	IC Instrument cluster
4	DFI Electronic distributor-type fuel injection (Diesel)	16	A/C Air conditioning, Models 124, 140, 202, 208, 210
4	IFI Electronic In-line fuel injection (Diesel)	16	TAU Tempmatic air conditioning, Model 170
4	HFM-SFI HFM sequential multiport fuel injection/ignition	17	DI Distributor ignition, Engines 104, 119, Engine 120 (right)
4	LH-SFI LH sequential multiport fuel injection, Engines 104, 119 Engine 120 (right)	17	TD-speed signal (time division) (diesel), Model 140
4	ME-SFI ME sequential multiport fuel injection/ignition, Engine 119, Engine 120 (right)	17	TN-speed signal, LH-SFI engines, HFM, Model 202
5	LH-SFI LH sequential multiport fuel injection, Engine 120 (left)	18	DI Distributor ignition, Engine 120 (left)
5	ME-SFI ME sequential multiport fuel injection/ignition, Engine 120 (left)	19	DM Diagnostic module USA
6	ABS Anti-lock brake system	20	PSE Pneumatic system equipment, Model 140
6	ETS Electronic traction system	20	CCM Combination control module, Model 210
6	ASR Acceleration slip regulation	21	CF Convenience feature, Model 140
6	ESP Electronic stability program	21	RST Roadster soft top, Model 129
7	EA Electronic accelerator	22	RB Roll bar, Model 129
7	CC/ISC Cruise control/idle speed control	23	ATA Anti-theft alarm
8	BM Base module	24-25	Not used
8	BAS Brake assist	26	ASD Automatic locking differential, Model 202
9	ASD Automatic locking differential, Models 124, 129, 140	27	Not used
10	ETC Electronic transmission control (A/T 5spd)	28	PTS Parktronic system, Model 140
10	ETC Electronic transmission control	29	Not used
11	ADS Adaptive damping system	30	AB Airbag/ETR (SRS)
12	SPS Speed-sensitive power steering	31	RCL Remote central locking
13	TNA-signal (gasoline), LH-SFI engines	32-33	Not used
13	TD-signal (Diesel), Model 210	34	CNS Communication and navigation system
		35	Not used
		36	Not used
		37-38	Not used



P00.19-0412-02

0 Connection and Use of Test Equipment

Connector Layout of Data Link Connector

16-pole Data Link Connector (X11/4 or X11/4s1)

Models 124 (except .034/036),


129 (except .060/066)

X11/4

1	Ground
2	Not used
3	CFI Continuous fuel injection (CIS-E)
4	EDS Electronic diesel system
5	4MATIC
6	AB Airbag/ETR (SRS)
7	A/C Air conditioning, Model 124
7	RB Roll bar, Model 129
8	DI Distributor ignition
8	HFM-SFI HFM sequential multiport fuel injection/ignition
8	PEC Pressurized engine control
9	ADS Adaptive damping system
9	RB Roll bar, Model 124
10	TN-signal (Gasoline)
11	ATA Anti-theft alarm
12	RCL Remote central locking
13	ETC Electronic transmission control
14	EA Electronic accelerator, Model 124
14	CC/ISC Cruise control/idle speed control, Model 124
14	ESCM Engine systems control module (MAS), Model 129
15	Not used
16	Circuit 15


X11/4s1 (with LED - California)

1	Ground
2	OBD Pushbutton for on-board diagnostics
3	CFI Continuous fuel injection (CIS-E)
3	DM Diagnostic module
4	LED
5	ASD Automatic locking differential
6	AB Airbag/ETR (SRS)
7	A/C Air conditioning, Model 124
7	RB Roll bar, Model 129
8	DI Distributor ignition
8	HFM-SFI HFM sequential multiport fuel injection/ignition
9	ADS Adaptive damping system
9	RB Roll bar, Model 124
10	RST Roadster soft top, Model 129
10	TN-signal (gasoline)
11	ATA Anti-theft alarm
12	RCL Remote central locking
13	ETC Electronic transmission control
14	EA Electronic accelerator, Model 124
14	CC/ISC Cruise control/idle speed control, Model 124
14	ESCM Engine systems control module (MAS), Model 129
15	Not used
16	Circuit 15



X11/4

P00.00-0926-01



P07.00-0322-01

0 Connection and Use of Test Equipment


Connector Layout of Data Link Connector

16-pole Data Link Connector (X11/22)

Model 163

X11/22

1	Not used
2	Not used
3	TNA-signal (gasoline)
4	Circuit 31, Ground
5	Circuit 31 (electronic ground)
6	CAN CAN interior bus (H)
7	ME Motor electronics (ME)
8	Circuit 87, voltage supply
9	ETS Electronic Traction System (ETS), Model 163
10	Not used
11	ETC Electronic transmission control (ETC)
12	AAM All-Activity-Module (AAM)
13	AB Airbag/ETR (SRS)
14	CAN CAN interior bus (L)
15	IC Instrument cluster
16	Circuit 30, voltage supply



P07.00-0323-10

0 Connection and Use of Test Equipment

Connecting Hand-Held Tester or Impulse Counter Scan Tool, Reading and Erasing Diagnostic Trouble Code Memory



Observe all system specific instructions listed in the "Preparation for Test" section of each Test Program.

Diagnostic trouble codes (DTC's) which have been stored due to testing or the disconnection of lines must be erased from the diagnostic trouble code memory at the end of testing.

- **Connect Hand-Held Tester (HHT) according to connection diagram:**


See 3/5, 6

The following functions can be performed according to the instructions on the display:

- a) Reading/erasing DTC memory
- b) Reading actual values


- c) Performing activations
- d) Programming control modules

Special Tools




965 589 00 01 00

Hand-held tester



965 589 00 40 00

Test cable



965 589 00 50 00

Adapter cable

0 Connection and Use of Test Equipment

Connecting Hand-Held Tester or Impulse Counter Scan Tool, Reading and Erasing Diagnostic Trouble Code Memory

- **Connect Impulse Counter Scan Tool (according to connection diagram).**

LED "U-Batt" must light up in the display.

If LED does not light up, check:

- a) Voltage supply.
- b) Impulse counter scan tool fuse.

1. Read Diagnostic Trouble Code Memory

- a) Ignition: **ON**
 - b) Press start button for 2 to 4 seconds.
 - c) Read and record diagnostic trouble code (DTC).
 - d) Press start button again for 2 to 4 seconds.
 - e) Read and record DTC.
- Repeat steps d) and e) until the first DTC reappears.

- 1) Erasing of stored diagnostic trouble codes must begin within 20 seconds of reading the DTC. After 20 seconds, the DTC can no longer be erased. Erasing procedure can be restarted by performing DTC memory readout after the fault is again displayed.




DTC readout is no longer possible using the impulse counter scan tool, with some systems, please review 12 in each system section prior to starting the DTC readout for the system being checked.

2. Clear Diagnostic Trouble Code Memory ¹⁾


- a) Press start button for 2 to 4 seconds (DTC appears)
- b) Wait 3 seconds, then press start button for 6 to 8 seconds, thereby erasing the previously displayed DTC from memory.
- c) Each stored DTC must be erased individually.

Special Tools



124 589 19 21 00

Pulse counter



140 589 14 63 00

Adapter

0 Connection and Use of Test Equipment

Connecting Hand-Held Tester or Impulse Counter Scan Tool, Reading and Erasing Diagnostic Trouble Code Memory

38-pole Data Link Connector (X11/4)

Connect impulse counter scan tool as follows:

Red wire (circuit 30, voltage): socket 3


Black wire (circuit 31, ground): socket 1

Yellow wire to diagnostic output socket of the system being tested.



Please see 3/5-6 for connection and use of HHT.

- 013 Impulse counter scan tool
- 075 Adaptor for impulse counter scan tool
- 087 Hand-Held Tester (HHT)
- 094 Multiplexer, 965 589 00 40
- X11/4 Data link connector



U07-5925-57

0 Connection and Use of Test Equipment

Connecting Hand-Held Tester or Impulse Counter Scan Tool, Reading and Erasing Diagnostic Trouble Code Memory

16-pole Data Link Connector (X11/4)

Connect HHT as follows:

Black wire (circuit 31, ground): socket 1
White wire (circuit 15, voltage): socket 16
Red wire (circuit 30): Battery +
or X4/10

Yellow wire to diagnostic output socket of the system being tested.


Connect impulse counter scan tool as follows:

Black wire (circuit 31, ground): socket 1
Red wire (circuit 15, ignition): socket 16

Yellow wire to diagnostic output socket of the system being tested.

- 013 Impulse counter scan tool (alternatively: Hand-Held Tester 087)
087 Hand-Held Tester (HHT) (alternatively: Impulse Counter Scan Tool)
X4/10 Terminal block, circuit 30
X11/4 Data link connector

Adapter cable, 965 589 00 50 00 (not shown)



U07-5730-57A

0 Connection and Use of Test Equipment

Connecting Hand-Held Tester, Reading and Erasing Diagnostic Trouble Code Memory

38-pole Data Link Connector (X11/4)

1. Connect HHT with Multiplexer (094) attached to Data link connector X11/4
2. Turn Ignition: **ON**
3. According to instructions in HHT display:
 - a) Readout DTC memory/erase
 - b) Readout Actual values
 - c) Perform Activations
 - d) Program control modules
4. Disconnect HHT.




Observe all system specific instructions listed in the "Preparation for Test" section of each Test Program.

Diagnostic trouble codes (DTC's) which have been stored due to testing or the disconnection of lines must be erased from the diagnostic trouble code memory at the end of testing.

087 Hand-Held Tester (HHT)
094 Multiplexer, 965 589 00 40
X11/4 Data link connector

Adapter cable, 965 589 00 50 00 (not shown)



P00.19-0411-06

0 Connection and Use of Test Equipment

Connecting Hand–Held Tester, Reading and Erasing Diagnostic Trouble Code Memory


16-pole Data Link Connector (X11/4) Model 163

1. Connect HHT with Multiplexer (094) and Adapter cable (107) attached, to Data link connector X11/4 (located in passenger compartment).
2. Turn Ignition: **ON**
3. According to instructions in HHT display:
 - a) Readout DTC memory/erase
 - b) Readout Actual values
 - c) Perform Activations
 - d) Program control modules
4. Disconnect HHT.



Observe all system specific instructions listed in the "Preparation for Test" section of each Test Program.

Diagnostic trouble codes (DTC's) which have been stored due to testing or the disconnection of lines must be erased from the diagnostic trouble code memory at the end of testing.



P42.35-0234-06

- 087 Hand–Held Tester (HHT)
094 Multiplexer, 965 589 00 40
107 Adapter cable (HHT) for X11/4, 16-pole connector
X11/4 Data link connector